

# EXPRESSI<sup>®</sup>

## CAPSULE COFFEE MACHINE



### QUICK START GUIDE

Model Number EXP-19CCMB

# PRODUCT OVERVIEW



## Capsule Coffee Machine

- |   |  |   |                                  |
|---|--|---|----------------------------------|
| 1 | Locking handle (for loading and ejecting capsules) | 5 | Coffee dispenser                 |
| 2 | Capsule compartment (underneath handle)            | 6 | Used capsule container           |
| 3 | Espresso button (short)                            | 7 | Adjustable cup support/drip tray |
| 4 | Lungo button (tall)                                | 8 | Water tank                       |
|   |  | 9 | Water tank lid                   |



**RISK OF INJURY!** Pointed needles open the capsule in the machine. To avoid injury do not reach into the capsule insertion opening.



Please read the safety instructions first.



Read the full instruction manual before use.  
This quick start guide only gives basic instructions.



**Recommendations for first start up:** Press the rinsing button 2 times to rinse the machine.



**WARNING: RISK OF SCALDING! VERY HOT WATER.**

# BEFORE FIRST USE

Rinse the water tank and ensure it is clean. Plug in the machine and fill the water tank up the “Max” line. Place a cup/container under the dispenser, press the espresso or lungo buttons repeatedly (with no capsule in the machine) until a full tank of water has been run through the machine. Your new capsule coffee machine is now ready for use.

## HOW TO USE


1

Plug-in the machine and fill the water up to the “Max” line. Place a cup/container under the dispenser.



2

Press the espresso (short) or lungo (tall) button to start preheating the machine. The lights on the button will flash for approx. 30 seconds. Once the button lights have stopped flashing, press either the espresso or lungo button to rinse the machine.



3

Lift the locking handle all the way and place a compatible coffee capsule into the compartment, then close the locking handle. Place your cup under the dispenser and press either the espresso or lungo button, the coffee will start to dispense.



4

Open and close the locking handle to release the spent capsule into the used capsule container.

# EXPRESSI<sup>®</sup>

CAPSULE COFFEE MACHINE

